


# JVC

## SERVICE MANUAL

### STEREO INTEGRATED AMPLIFIER

MODEL No. **AX-440BK**



## Contents

|                          | Page |                                      | Page                      |
|--------------------------|------|--------------------------------------|---------------------------|
| Safety Precautions ..... | 1-2  | Adjustment Procedures .....          | 1-8                       |
| Front Panel .....        | 1-3  | Schematic Diagram .....              | Insertion                 |
| Operation .....          | 1-4  | Connection Diagram .....             | Insertion                 |
| Specifications .....     | 1-5  | Parts List .....                     | Separate Volume Insertion |
| Block Diagram .....      | 1-6  | Internal Block Diagrams of ICs ..... | 1-9                       |
| Removal Procedures ..... | 1-7  |                                      |                           |

## Safety Precautions

1. The design of this product contains special hardware and many circuits and components specially for safety purposes.

For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits. Service should be performed by qualified personnel only.

2. Alterations of the design or circuitry of the product should not be made. Any design alterations or additions will void the manufacturer's warranty and will further relieve the manufacturer of responsibility for personal injury or property damage resulting therefrom.
3. Many electrical and mechanical parts in the product have special safety-related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in the Parts List of Service Manual. Electrical components having such features are identified by shading on the schematics and by ( $\Delta$ ) on the Parts List in the Service Manual. The use of a substitute replacement which does not have the same safety characteristics as the recommended replacement part shown in the Parts List of Service Manual may create shock, fire, or other hazards.
4. The leads in the products are routed and dressed with ties, clamps, tubings, barriers and the like to be separated from live parts, high temperature parts, moving parts and/or sharp edges or the prevention of electric shock and fire hazard.

When service is required, the original lead routing and dress should be observed, and it should be confirmed that they have been returned to normal, after re-assembling.

5. Leakage current check

(Electrical shock hazard testing)

After re-assembling the product, always perform an isolation check on the exposed metal parts of the product (antenna terminals, knobs, metal cabinet, screw heads, headphone jack, control shafts, etc.) to be sure the product is safe to operate without danger of electrical shock.

Do not use a line isolation transformer during this check.


- Plug the AC line cord directly into the AC outlet. Using a "Leakage Current Tester", measure the leakage current from each exposed metal part of the cabinet, particularly any exposed metal part having a return path to the chassis, to a known good earth ground. Any leakage current must not exceed 0.5 mA AC (r.m.s.).

- Alternate check method.

Plug the AC line cord directly into the AC outlet. Use an AC voltmeter having 1,000 ohms per volt or more sensitivity in the following manner. Use an AC line cord directly into the AC outlet. Connect a 1,500  $\Omega$  10 W resistor paralleled by a 0.15  $\mu$ F AC-type capacitor between an exposed metal part and a known good earth ground.

Measure the AC voltage across the resistor with the AC voltmeter.

Move the resistor connection to each exposed metal part, particularly any exposed metal part having a return path to the chassis, and measure the AC voltage across the resistor. Now, reverse the plug in the AC outlet and repeat each measurement. Any voltage measured must not exceed 0.75 V AC (r.m.s.). This corresponds to 0.5 mA AC (r.m.s.).



### CHECK THE VOLTAGE SELECTOR'S SETTING

(Except for U.S.A., Canada, Australia, U.K. and Continental Europe.)


Before inserting the power plug, please check that the voltage selector's setting corresponds with the line voltage in your area. If it doesn't, be sure to reset the voltage selector before this equipment.

The voltage selector may be located on the rear or bottom of the unit, or underneath the platter.

**CAUTION:** Before setting the voltage selector to the proper voltage, disconnect the power plug.

## FRONT PANEL

These instructions are prepared for three models: AX-330BK/AX-440BK/AX-550BK. Therefore, read the items below concerning each model.



## 1 POWER

**ON (—):** Press this button to turn the power on.  
**OFF (■):** Set to this position to turn the power off.

## Notes:

- When power is not supplied to this amplifier for 2 – 3 days, the source select button pressed before the power was switched off may be lost when the power is switched on again. If this happens, set the buttons, etc. again.
- An electronic source selector is used in this unit. When the POWER button is first switched on, two or more sources or no source may be selected. Make sure to input the source select data by pressing one of the source selectors.
- If the POWER button is pressed repeatedly to switch on and off too quickly, the same phenomenon as the above will occur.

## 2 SOURCE INDICATOR

The indicator corresponding to the source select button pressed lights.

## 3 TAPE 1 MONITOR

Press to listen to a tape deck connected to the TAPE 1 terminals.

## 4 AUX

Press to listen to the source connected to the AUX terminals.

## 5 TUNER

Press to listen to radio broadcasts by a tuner connected to the TUNER terminals.

## 6 CD

Press to listen to the source connected to the CD terminals.

## 7 PHONO

Press to listen to records played by a turntable connected to the PHONO terminals.

## 8 Gm SELECTOR indicators (AX-550BK)

These indicators are illuminated according to the setting of the Gm SELECTOR.

**0 dB:** Set the Gm SELECTOR so that this indicator lights when listening to a high-volume level.

**-6 dB:** Set the Gm SELECTOR so that this indicator lights when listening to a middle-volume level.

**-12 dB:** Set the Gm SELECTOR so that this indicator lights when listening to a low-volume level.

## 9 Gm SELECTOR (AX-550BK)

Setting the Gm selector to -6 dB divides the volume at 0 dB by 4 while setting it to -12 dB divides it by 16. As the Gm selector is turned from 0 dB to -6 dB and -12 dB, residual noise becomes progressively less. Use the Gm selector together with the VOLUME control.

## 10 VOLUME

Controls the volume of the speakers and headphones.

## 11 PHONES (Headphones jack)

Plug stereo headphones into this jack for private listening.

## 12 SPEAKERS

Press to switch the speakers connected to the SPEAKERS 1 or 2 terminals on (—) and off (■).

## Note: (AX-330BK, AX-440BK)

- When speakers are connected to only one pair of SPEAKERS terminals, press only the SPEAKERS button of the system connected; if both buttons are pressed, sound will not be heard from either speaker system. When two pairs of speakers are connected and either or both SPEAKERS buttons is/are pressed, sound will be heard from either or both speaker system(s).

## 13 BASS

Turn clockwise to boost bass response and counterclockwise to decrease it.

## 14 TREBLE

Turn clockwise to boost treble response and counterclockwise to decrease it.

## 15 TONE (AX-440BK, AX-550BK)

**ON (—):** Press to adjust the tone with the BASS and TREBLE controls.

**DEFAT (■):** Press to this position to obtain a standard (flat) frequency response.

## 16 TAPE 2 MONITOR

**ON (—):** Set to this position to listen to the tape deck connected to the TAPE 2 terminals of this unit. If your tape deck is of the 3-head type, you can monitor the recorded sound while recording by setting this button to ON.

**OFF (■):** Keep this button set to this position, except when you want to listen to the tape deck connected to the TAPE 2 terminals of this unit.

## 17 MODE (AX-440BK, AX-550BK)

**MONO (—):** Set to this position to have both speakers produce the sound of both the left- and right-channel signals mixed.  
**STEREO (■):** Normally set to this position.

## 18 CARTRIDGE (AX-440BK, AX-550BK)

**MC (—):** Press in when using an MC cartridge having an output of less than 0.5 mV.  
**MM (■):** Press again when using an MM or MC cartridge having an output of more than 0.5 mV.

## 19 LOUDNESS

**ON (—):** To compensate for the ear's lower sensitivity at low listening levels.  
**OFF (■):** To bypass the LOUDNESS circuit.

## 20 BALANCE

Balances the volume between the left and right speakers. Usually set it to the center click position.

## OPERATION

Before operation, always be sure to set **VOLUME** at minimum.

When the volume is increased after selecting a source position with no equipment connected to the input terminal, other connected devices (such as speakers) may be adversely affected by external noise and inductive hum.

## Listening to broadcasts

1. Connect a tuner to the TUNER terminals on the rear panel.
2. Press the POWER button on.
3. Press the TUNER button and make sure that the TAPE 1 MONITOR and TAPE 2 MONITOR buttons are set to off.
4. Select the speaker system with the SPEAKERS switches.
5. Operate the tuner according to its instruction manual.
6. Adjust the VOLUME, LOUDNESS, BALANCE and BASS/TREBLE controls.

## Listening to records

1. Connect a turntable to the PHONO terminals on the rear panel.
2. Press the POWER button on.
3. Set the CARTRIDGE button of this unit according to the cartridge in use. (AX-440BK, AX-550BK)
4. Press the PHONO button and make sure that the TAPE 1 MONITOR and TAPE 2 MONITOR buttons are set to off.
5. Select the speaker system with the SPEAKERS switches.
6. Operate the turntable according to its instruction manual.
7. Adjust the VOLUME, LOUDNESS, BALANCE and BASS/TREBLE controls.

## Listening to tapes

To listen to the tape deck connected to the TAPE 1 or TAPE 2 terminals.

1. Connect a tape deck to the PLAY terminals of TAPE 1 or TAPE 2.
2. Press the POWER button on.
3. Press the TAPE 1 MONITOR button to play back the TAPE 1 deck. For playback of the TAPE 2 deck, press the TAPE 2 MONITOR button to ON (—).
4. Select the speaker system with the SPEAKERS switches.
5. Operate the tape deck for playback according to its instruction manual.
6. Adjust the playback sound controls as required.

## Notes:

- Do not place the tape deck directly on the amplifier, because it may cause the amplifier to malfunction.

## Using stereo headphones

Stereo headphones can be plugged into the front panel jack. Plugging headphones into the PHONES jack does not switch off the speaker sound.

## Recording tapes

- To record from disc sources on to a tape deck.
1. Connect a tape deck to the REC terminals of the TAPE 1 or TAPE 2 terminals.
  2. Press the POWER button on.
  3. Select a speaker system if you wish to hear the sound while recording.
  4. Press the PHONO button.
  5. Operate the turntable.
  6. Operate the tape deck for recording.

## To record from other sources (TUNER, CD, AUX)

Press the TUNER, CD or AUX button to record radio broadcasts, or the source connected to the CD, AUX terminals.

All other operations are identical to when recording from disc source.

## Tape dubbing

Dubbing from the TAPE 1 to TAPE 2 is carried out as follows:

1. Press the TAPE 1 MONITOR button.
2. Play back the TAPE 1 deck.
3. Operate the TAPE 2 deck for recording.

## Notes:

- You can also monitor the sound being recorded with headphones.
- The sound you hear from the speakers or headphones is the source sound, not that being recorded on the tape.
- Dubbing from TAPE 2 to TAPE 1 is not possible.
- The VOLUME control of this amplifier has no effect on the recording level. Adjust the recording level with the controls on the tape deck.
- While playing back a tape on the tape deck (to which the TAPE 2 terminals of this unit are connected), you cannot record the sources from other components.

## How to operate the monitor while recording on the tape deck

1. Connect a 3-head tape deck to the TAPE 1 or TAPE 2 terminals.
2. Make sure to connect the signal cords to the PLAY and REC terminals.
3. Select the source from which you want to record by depressing the source select button on this unit.
4. Operate the tape deck for recording as described in its operating manual.
5. By playing the source component, you can record on the tape deck.
6. While recording on the tape deck, the recorded sound can be heard by depressing the TAPE 1 MONITOR or TAPE 2 MONITOR button on this unit.

## Use of S.E.A. Graphic Equalizer

The S.E.A. Graphic Equalizer is JVC's exclusive tone control system. By allowing you to independently boost or lower the response of finely divided sections of the frequency spectrum; the S.E.A. gives you much greater control over the sound quality of your stereo system. With an optionally available S.E.A. Graphic Equalizer, you can tailor the sound to your own taste for different types of music or to compensate for the particular acoustic characteristics of your audio components and listening room.

The TAPE 2 terminals of the AX-330BK, AX-440BK or AX-550BK can be used for connecting the S.E.A. Graphic Equalizer.

## TROUBLESHOOTING

What appears to be a malfunction may not always be serious.

Make sure first . . .

No sound and no light

Is the AC plug connected properly?  
Are the connections made correctly?

No sound from speakers

Are speaker cords connected?  
Are the SPEAKERS buttons correctly set?

Is the VOLUME control properly set?  
Is your source component correctly set?

Sound from one speaker only

Are speaker cords connected correctly?  
Is BALANCE control set to one extreme or the other?

Loud hum during record playing

Is turntable grounded?

Try to change cord path.

Howling noise during record playing

Is turntable too close to a speaker?

## SPECIFICATIONS

**AX-330BK****OVERALL CHARACTERISTICS**

Output power : 60 watts per channel into 8 ohms at 1 kHz (DIN).  
 55 watts per channel, min. RMS, both channels driven, into 8 ohms from 20 Hz to 20 kHz, with no more than 0.007 % total harmonic distortion.  
 55 watts per channel, min. RMS, both channels driven, into 8 ohms at 1 kHz with no more than 0.003 % total harmonic distortion. (measured by JVC Audio Analyzer System)

Total harmonic distortion : 0.007 % (20 Hz — 20 kHz, 8 ohms) at 55 watts  
 Intermodulation distortion : 0.007 % (60 Hz : 7 kHz = 4:1, 8 ohms) at 55 watts  
 Power band width : 5 Hz — 50 kHz (IHF, 0.05 %, 8 ohms both channels driven)  
 Frequency response : 5 Hz — 80 kHz +0, -3 dB (8 ohms)  
 Damping factor : 35 (1 kHz, 8 ohms)  
 Input terminals  
 Input sensitivity/impedance (1 kHz)  
 PHONO : 2.5 mV/47 kohms  
 CD/AUX/TUNER/ : 150 mV/43 kohms  
 TAPE 1, 2  
 Signal-to-noise ratio  
 PHONO : 71 dB ('66 IHF)  
 CD/AUX/TUNER/ : 100 dB ('66 IHF)  
 TAPE 1, 2  
 PHONO : 80 dB ('78 IHF)  
 (REC OUT)  
 CD/AUX/TUNER/ : 76 dB ('78 IHF)  
 TAPE 1, 2 (SP OUT)  
 PHONO : 67 dB (DIN)  
 CD/AUX/TUNER/ : 68 dB (DIN)  
 TAPE 1, 2  
 Tone controls : TREBLE: +8 ±1 dB -8 ±1 dB (at 10 kHz)  
 BASS: +8 ±1 dB -8 ±1 dB (at 100 Hz)

Loudness controls : +6 dB (at 100 Hz)  
 (Volume control at -30 dB position)

**EQUALIZER**

PHONO overload capacity : 100 mV (0.02 % THD)  
 PHONO RIAA deviation

PHONO : ±0.5 dB (20 Hz — 20 kHz)

Recording output  
 Output level/impedance  
 TAPE REC-1, 2 : 150 mV/2 kohms

**GENERAL**

Dimensions : 435(W) x 117(H) x 306(D) mm  
 (17-3/16" x 4-5/8" x 12-1/16")  
 Weight : 5.7 kg (12.6 lbs.)

Design and specifications subject to change without notice.

**AX-440BK****OVERALL CHARACTERISTICS**

Output power : 85 watts per channel into 8 ohms at 1 kHz (DIN).  
 75 watts per channel, min. RMS, both channels driven, into 8 ohms from 20 Hz to 20 kHz, with no more than 0.007 % total harmonic distortion.  
 80 watts per channel, min. RMS, both channels driven, into 8 ohms at 1 kHz with no more than 0.003 % total harmonic distortion. (measured by JVC Audio Analyzer System)

Total harmonic distortion : 0.007 % (20 Hz — 20 kHz, 8 ohms) at 75 watts  
 Intermodulation distortion : 0.007 % (60 Hz : 7 kHz = 4:1, 8 ohms) at 75 watts  
 Power band width : 5 Hz — 50 kHz (IHF, 0.05 %, 8 ohms both channels driven)  
 Frequency response : 5 Hz — 90 kHz +0, -3 dB (8 ohms)  
 Damping factor : 50 (1 kHz, 8 ohms)  
 Input terminals  
 Input sensitivity/impedance (1 kHz)  
 PHONO (MM) : 2.5 mV/47 kohms  
 PHONO (MC) : 200 μV/100 ohms  
 CD/AUX/TUNER/ : 200 mV/43 kohms  
 TAPE 1, 2  
 Signal-to-noise ratio  
 PHONO (MM) : 86 dB ('66 IHF)  
 PHONO (MC) : 67 dB ('66 IHF)  
 CD/AUX/TUNER/ : 101 dB ('66 IHF)  
 TAPE 1, 2  
 PHONO (MM) : 82 dB ('78 IHF)  
 (REC OUT)  
 PHONO (MC) : 75 dB ('78 IHF)  
 CD/AUX/TUNER/ : 76 dB ('78 IHF)  
 TAPE 1, 2 (SP OUT)  
 PHONO (MM) : 67 dB (DIN)  
 PHONO (MC) : 67 dB (DIN)  
 CD/AUX/TUNER/ : 68 dB (DIN)  
 TAPE 1, 2  
 Tone controls : TREBLE: +8 ±1 dB -8 ±1 dB (at 10 kHz)  
 BASS: +8 ±1 dB -8 ±1 dB (at 100 Hz)

Loudness controls : +6 dB (at 100 Hz)  
 (Volume control at -30 dB position)

**EQUALIZER**

PHONO overload capacity : 100 mV (0.02 % THD)  
 PHONO (MC) : 8 mV (0.04 % THD)  
 PHONO RIAA deviation

PHONO (MM) : ±0.3 dB (20 Hz — 20 kHz)  
 PHONO (MC) : ±0.5 dB (20 Hz — 20 kHz)

Recording output  
 Output level/impedance  
 TAPE REC-1, 2 : 200 mV/1.8 kohms

**GENERAL**

Dimensions : 435(W) x 117(H) x 306(D) mm  
 (17-3/16" x 4-5/8" x 12-1/16")

Weight : 6.4 kg (14.1 lbs.)

Design and specifications subject to change without notice.

**AX-550BK****OVERALL CHARACTERISTICS**

Output power : 100 watts per channel into 8 ohms at 1 kHz (DIN).  
 90 watts per channel, min. RMS, both channels driven, into 8 ohms from 20 Hz to 20 kHz, with no more than 0.007 % total harmonic distortion.  
 90 watts per channel, min. RMS, both channels driven, into 8 ohms at 1 kHz with no more than 0.003 % total harmonic distortion. (measured by JVC Audio Analyzer System)

Total harmonic distortion : 0.007 % (20 Hz — 20 kHz, 8 ohms) at 90 watts  
 Intermodulation distortion : 0.007 % (60 Hz : 7 kHz = 4:1, 8 ohms) at 90 watts  
 Power band width : 5 Hz — 50 kHz (IHF, 0.05 %, 8 ohms both channels driven)  
 Frequency response : 5 Hz — 100 kHz +0, -3 dB (8 ohms)  
 Damping factor : 60 (1 kHz, 8 ohms)  
 Input terminals  
 Input sensitivity/impedance (1 kHz)  
 PHONO (MM) : 2.5 mV/47 kohms  
 PHONO (MC) : 200 μV/100 ohms  
 CD/AUX/TUNER/ : 200 mV/43 kohms  
 TAPE 1, 2  
 Signal-to-noise ratio  
 PHONO (MM) : 86 dB ('66 IHF)  
 PHONO (MC) : 68 dB ('66 IHF)  
 CD/AUX/TUNER/ : 101 dB ('66 IHF)  
 TAPE 1, 2  
 PHONO (MM) : 82 dB ('78 IHF)  
 (REC OUT)  
 PHONO (MC) : 75 dB ('78 IHF)  
 CD/AUX/TUNER/ : 76 dB ('78 IHF)  
 TAPE 1, 2 (SP OUT)  
 PHONO (MM) : 67 dB (DIN)  
 PHONO (MC) : 67 dB (DIN)  
 CD/AUX/TUNER/ : 68 dB (DIN)  
 TAPE 1, 2  
 Tone controls : TREBLE: +8 ±1 dB -8 ±1 dB (at 10 kHz)  
 BASS: +8 ±1 dB -8 ±1 dB (at 100 Hz)

Loudness controls : +6 dB (at 100 Hz)  
 (Volume control at -30 dB position)

**EQUALIZER**

PHONO overload capacity : 100 mV (0.02 % THD)  
 PHONO (MC) : 8 mV (0.04 % THD)  
 PHONO RIAA deviation

PHONO (MM) : ±0.3 dB (20 Hz — 20 kHz)  
 PHONO (MC) : ±0.5 dB (20 Hz — 20 kHz)

Recording output  
 Output level/impedance  
 TAPE REC-1, 2 : 200 mV/1.8 kohms


**GENERAL**

Dimensions : 435(W) x 117(H) x 350(D) mm  
 (17-3/16" x 4-5/8" x 13-13/16")

Weight : 8.6 kg (19.0 lbs.)


Design and specifications subject to change without notice.

## Block Diagram

**POWER SPECIFICATIONS**

| Areas              | Line voltage & frequency                   | Power consumption |           |           |
|--------------------|--|-------------------|-----------|-----------|
|                    |  | AX-330BK          | AX-440BK  | AX-550BK  |
| Continental Europe | AC 220 V~, 50 Hz                           | 160 watts         | 190 watts | 210 watts |
| U.K.               | AC 240 V~, 50 Hz                           | 160 watts         | 190 watts | 210 watts |
| Australia          |  |                   |           |           |
| Other areas        | AC 110/120/220/240 V~ selectable, 50/60 Hz | 160 watts         | 190 watts | 210 watts |

## Removal Procedures



### ■ Removing the Metal Cover

1. Remove six screws.
2. Remove the metal cover by lifting up its rear section and pulling it backward while holding it on incline.

### ■ Removing the Front Panel

1. Remove the metal cover.
2. Pull out the volume knob and remove the nut.
3. Remove three plastic rivets on the upper part of the front panel and three screws from the lower part.

### ■ Removing the Power Transistors




1. Remove the metal cover.
2. Remove screws ① – ④.
3. Raise the main amp PC board so that the pattern side faces up.
4. Remove solder from the power transistors.
5. Remove screws ⑤, ⑥ and remove the heatsinks together with the power transistors.
6. Remove the retaining screw from the defective power transistor and replace it.

## ■ Use of New-type Connector

(1) Slide the cover upward.


(2) Extract the wires.

(3) Insert the wires after pushing in the cover.



## Adjustment Procedures

### ■ Power Amplifier Idling Adjustment



ENH-090-1

1. Before tuning on the power, turn the semi-fixed resistors (R751 for L channel and R752 for R channel) of the power amplifier circuit board fully counterclockwise.

2. Adjust the semi-fixed resistor (R751 and R752) so that the voltage at the following test points of the power amplifier circuit board is within a range of 3 ~ 5 mV after the power is turned on.

L channel: Measure the voltage between test point ① (emitter of Q761) and output at the test point ②.

R channel: Measure the voltage between test point ③ (emitter of Q762) and output at the test point ④.

3. Readjust resistors R751 and R752 about 10 minutes after the power is turned on (the heatsink temperature must be sufficiently high) so that the voltage at the test points becomes 11 mV.


Confirm that the voltage does not vary when the heatsink temperature increases further.



**Note:** Be sure to perform the measurement with the probes and cabinet of the measuring equipment separated from the grounding terminals of AX-440BK or other measuring equipment.



## Schematic Diagram

**Notes:**



1.  shows DC voltage to the
2.  indicates  $\pm$  B power sup
3.  indicates signal path.











# PARTS LIST

## Contents

Main Parts Locations..... 2-2

Dxploded View and Parts List ..... 2-3

Printed Circuit Board Ass’y and Parts List..... 2-6

■ ENH-090 □ Power Amplifier PC Board Ass’y ..... 2-6

■ ENE-034 □ Source Select PC Board Ass’y ..... 2-9


■ TPS-318 A Voltage Selector PC Board Ass’y ..... 2-11

Packing Materials and Part Numbers ..... 2-12


Accessories List ..... 2-12

# Main Parts Locations


## Front View




## Top View



## Rear View








Exploded View and Parts List



| ⚠ | Item No. | Part Number    | Part Name              | Q'ty | Description | Areas             |
|---|----------|----------------|------------------------|------|-------------|-------------------|
|   | 1        | EFP-AX-440BKE  | Front Panel Ass'y      | 1    |             |                   |
|   | 1-1      | E25584-002     | Front Panel            | 1    |             |                   |
|   | 1-2      | E72968-001     | JVC Mark               | 1    |             |                   |
|   | 1-3      | E60912-003     | Speed Nut              | 1    |             |                   |
|   | 1-4      | E73878-001     | Push Button Escutcheon | 1    |             |                   |
|   | 1-5      | E304602-001    | IND. Sheet             | 1    |             |                   |
|   | 1-6      | E72437-010     | Sheet                  | 1    |             |                   |
|   | 1-7      | E304646-001    | Push Button Ass'y      | 1    |             |                   |
|   | 1-8      | E73836-001     | Push Button Escutcheon | 7    |             |                   |
|   | 1-9      | E304603-001    | Knob Ring              | 1    |             |                   |
|   | 1-10     | E74025-001     | Sheet                  | 1    |             |                   |
|   | 2        | E302479-004    | Volume Knob            | 1    |             |                   |
|   | 3        | E72517-004     | Knob                   | 3    |             |                   |
|   | 4        | E73835-001     | Push Button            | 7    |             |                   |
|   | 5        | E73877-001     | Push Button            | 1    |             |                   |
|   | 6        | E73218-001     | Head Phone Bracket     | 1    |             |                   |
|   | 7        | SBSB3008CC     | Screw                  | 7    |             |                   |
|   | 8        | SBST3006CC     | Screw                  | 13   |             |                   |
|   | 9        | E48729-008     | Plastic Rivet          | 4    |             |                   |
|   | 10       | E25586-001     | Front Bracket          | 1    |             |                   |
|   | 11       | E48729-009     | Plastic Rivet          | 3    |             |                   |
|   | 12       | SBSB3008M      | Screw                  | 5    |             |                   |
|   | 13       | E24721-008     | Metal Cover            | 1    |             | P, PG, A, G, U    |
|   |          | E25026-004     | Metal Cover            | 1    |             | E, BS             |
|   | 14       | E23862-005     | Grille                 | 1    |             | E, BS             |
|   | 15       | E61660-004     | Special Screw          | 4    |             |                   |
|   | 16       | EXO060007N40S  | Spacer                 | 2    |             |                   |
|   | 17       | SBST3006Z      | Screw                  | 4    |             |                   |
| ⚠ | 18       | QSP1106-005    | Push Switch            | 1    | Power       | P, PG, U          |
| ⚠ |          | QSP1106-004    | Push Switch            | 1    | Power       | E, A, G           |
| ⚠ |          | QSP1106-004BS  | Push Switch            | 1    | Power       | BS                |
|   | 19       | E71004-001     | Switch Cover           | 1    |             |                   |
|   | 20       | E10717-011     | Chassis Base           | 1    |             |                   |
|   | 21       | E47227-012     | Foot                   | 4    |             |                   |
|   | 22       | SBSB3010Z      | Screw                  | 4    |             |                   |
|   | 23       | E65778-002     | Spacer                 | 1    |             |                   |
|   | 24       | QHW3059-001    | Wire Clamp             | 1    |             |                   |
|   | 25       | E71335-002     | Fastener               | 1    |             |                   |
|   | 26       | E65389-002     | Screw                  | 4    |             |                   |
| ⚠ | 27       | ETP1150-20FA   | Power Transformer      | 1    |             | P, PG, U          |
| ⚠ |          | ETP1150-20EA   | Power Transformer      | 1    |             | E, A, G           |
| ⚠ |          | ETP1150-20EABS | Power Transformer      | 1    |             | BS                |
|   | 28       | E34455-001     | Fastener               | 1    |             |                   |
| ⚠ | 29       | QMF51A2-4R0S   | Fuse                   | 1    | F001        | P, PG, U          |
| ⚠ | 30       | QMF51A2-2R5S   | Fuse                   | 1    | F002        | P, PG, U          |
| ⚠ |          | QMF51A2-2R5S   | Fuse                   | 1    | F003        | E, A, G           |
| ⚠ |          | QMF51E2-2R5SBS | Fuse                   | 1    | F003        | BS                |
|   | 31       | E25549-005     | Rear Panel             | 1    |             | P, PG, U          |
|   |          | E25549-008     | Rear Panel             | 1    |             | E, A, G, BS       |
|   | 32       | E73273-001     | Screw                  | 14   |             |                   |
|   | 33       | SDSB3008M      | Screw                  | 2    |             | P, PG, U          |
| ⚠ | 34       | E70078-001     | GND Terminal           | 1    |             |                   |
| ⚠ | 35       | QHS3876-162    | Cord Stopper           | 1    |             | P, PG, E, A, G, U |
| ⚠ |          | QHS3876-162BS  | Cord Stopper           | 1    |             | BS                |

⚠ : Safety Parts

|  | Item No. | Part Number   | Part Name      | Q'ty | Description | Areas    |
|---|----------|---------------|----------------|------|-------------|----------|
|  | 36       | QMP2560-244   | Power Cord     | 1    |             | A        |
|  |          | QMP3900-200   | Power Cord     | 1    |             | E, G     |
|  |          | QMP7600-200   | Power Cord     | 1    |             | P, PG, U |
|  |          | QMP9017-008BS | Power Cord     | 1    |             | BS       |
|   | 37       | E303823-001   | Protector      | 1    |             |          |
|   | 38       | E74074-002    | Shield Bracket | 1    |             |          |
|   | 39       | E3400-384     | Felt Spacer    | 1    |             |          |
|   | 40       | E69384-002    | Fastener       | 1    |             |          |
|   | —        | E303260-096   | Rating Label   | 1    |             | E, G     |




: Safety Parts


The Marks for Designated Areas

- P, PG..... U.S. Military Market
- E ..... Europe
- A..... Australia
- G..... West Germany
- BS..... U.K.
- U ..... Other Countries
- No mark indicates all areas.

## Printed Circuit Board Ass'y and Parts List

■ ENH-090 □ Power Amplifier PC Board Ass'y  
Note: ENH-090 □ Varies according to the areas employed. See note (1) when placing an order.  
Note (1)

| PC Board Ass'y  | Designated Areas                          |
|---|---|
| ENH-090  | U.S. Military Market<br>& Other Countries |
| ENH-090  | Europe, Australia, U.K.                   |
| ENH-090  | West Germany                              |





TRANSISTORS

| △ | ITEM | PART NUMBER    | DESCRIPTION |            | AREA |
|---|------|----------------|-------------|------------|------|
|   |      |                |             | MAKER      |      |
|   | Q701 | 2SC2240(A,B)   | SILICON     | TOSHIBA    |      |
|   | Q702 | 2SC2240(A,B)   | SILICON     | TOSHIBA    |      |
|   | Q703 | 2SC2240(A,B)   | SILICON     | TOSHIBA    |      |
|   | Q704 | 2SC2240(A,B)   | SILICON     | TOSHIBA    |      |
|   | Q705 | 2SA970(GR,BL)  | SILICON     | TOSHIBA    |      |
|   | Q706 | 2SA970(GR,BL)  | SILICON     | TOSHIBA    |      |
|   | Q707 | 2SA970(GR,BL)  | SILICON     | TOSHIBA    |      |
|   | Q708 | 2SA970(GR,BL)  | SILICON     | TOSHIBA    |      |
|   | Q709 | 2SA933LN(R,S)  | SILICON     | ROHM       |      |
|   | Q710 | 2SA933LN(R,S)  | SILICON     | ROHM       |      |
|   | Q711 | 2SC2240(GR,BL) | SILICON     | TOSHIBA    |      |
|   | Q712 | 2SC2240(GR,BL) | SILICON     | TOSHIBA    |      |
|   | Q751 | 2SD636(Q,R)    | SILICON     | MATSUSHITA |      |
|   | Q752 | 2SD636(Q,R)    | SILICON     | MATSUSHITA |      |
|   | Q753 | 2SC2240(GR,BL) | SILICON     | TOSHIBA    |      |
|   | Q754 | 2SC2240(GR,BL) | SILICON     | TOSHIBA    |      |
|   | Q755 | 2SA970(GR,BL)  | SILICON     | TOSHIBA    |      |
|   | Q756 | 2SA970(GR,BL)  | SILICON     | TOSHIBA    |      |
|   | Q757 | 2SC2235(O,Y)   | SILICON     | TOSHIBA    |      |
|   | Q758 | 2SC2235(O,Y)   | SILICON     | TOSHIBA    |      |
|   | Q759 | 2SA965(O,Y)    | SILICON     | TOSHIBA    |      |
|   | Q760 | 2SA965(O,Y)    | SILICON     | TOSHIBA    |      |
|   | Q761 | 2SD1148LB(O,R) | SILICON     | TOSHIBA    |      |
|   | Q762 | 2SD1148LB(O,R) | SILICON     | TOSHIBA    |      |
|   | Q763 | 2SB863LB(O,R)  | SILICON     | TOSHIBA    |      |
|   | Q764 | 2SB863LB(O,R)  | SILICON     | TOSHIBA    |      |
|   | Q775 | 2SC1740(R,S)   | SILICON     | ROHM       |      |
|   | Q776 | 2SC1740(R,S)   | SILICON     | ROHM       |      |
|   | Q777 | 2SA933(R,S)    | SILICON     | ROHM       |      |
|   | Q778 | 2SA933(R,S)    | SILICON     | ROHM       |      |
|   | Q801 | 2SD1666(R,S)   | SILICON     | SANYO      |      |
|   | Q802 | 2SB1133(R,S)   | SILICON     | SANYO      |      |
|   | Q803 | 2SA933(R,S)    | SILICON     | ROHM       |      |
|   | Q805 | 2SC1740(R,S)   | SILICON     | ROHM       |      |
|   | Q901 | 2SC2240(GR,BL) | SILICON     | TOSHIBA    |      |
|   | Q902 | 2SC2240(GR,BL) | SILICON     | TOSHIBA    |      |
|   | Q903 | 2SA970(GR,BL)  | SILICON     | TOSHIBA    |      |

I. C. S

| △ | ITEM  | PART NUMBER | DESCRIPTION |         | AREA |
|---|-------|-------------|-------------|---------|------|
|   |       |             |             | MAKER   |      |
|   | IC751 | VC5022(X,Y) | I.C.        | ROHM    |      |
|   | IC752 | VC5022(X,Y) | I.C.        | ROHM    |      |
|   | IC901 | TA7317P     | I.C.        | TOSHIBA |      |

DIODES

| △ | ITEM | PART NUMBER | DESCRIPTION |            | AREA |
|---|------|-------------|-------------|------------|------|
|   |      |             |             | MAKER      |      |
|   | D701 | 1S2076-31   | SILICON     | HITACHI    |      |
|   | D702 | 1S2076-31   | SILICON     | HITACHI    |      |
|   | D703 | 1S2076-31   | SILICON     | HITACHI    |      |
|   | D704 | 1S2076-31   | SILICON     | HITACHI    |      |
|   | D761 | 1S2076-31   | SILICON     | HITACHI    |      |
|   | D762 | 1S2076-31   | SILICON     | HITACHI    |      |
|   | D763 | 1S2076-31   | SILICON     | HITACHI    |      |
|   | D764 | 1S2076-31   | SILICON     | HITACHI    |      |
|   | D801 | S3V20F      | SILICON     | SHINDENGEN |      |
|   | D802 | S3V20F      | SILICON     | SHINDENGEN |      |
|   | D803 | S3V20F      | SILICON     | SHINDENGEN |      |
|   | D804 | S3V20F      | SILICON     | SHINDENGEN |      |
|   | D805 | HZ15-1L     | SILICON     | HITACHI    |      |
|   | D806 | 1S2076-31   | SILICON     | HITACHI    |      |
|   | D807 | RD18EB3     | ZENER       | NEC        |      |
|   | D808 | 1S2076-31   | SILICON     | HITACHI    |      |
|   | D809 | RD18EB3     | ZENER       | NEC        |      |
|   | D810 | RD18EB3     | ZENER       | NEC        |      |
|   | D901 | 1S2076-31   | SILICON     | HITACHI    |      |
|   | D902 | 1S2076-31   | SILICON     | HITACHI    |      |
|   | D903 | 1S2076-31   | SILICON     | HITACHI    |      |
|   | D904 | 1S2076-31   | SILICON     | HITACHI    |      |
|   | D905 | 1S2076-31   | SILICON     | HITACHI    |      |

GAPACITORS

| △ | ITEM | PART NUMBER  | DESCRIPTION |       | AREA     |
|---|------|--------------|-------------|-------|----------|
|   |      |              |             | MAKER |          |
|   | C501 | QFN81HK-153  | 0.015MF     | 50V   | MYLAR    |
|   | C502 | QFN81HK-153  | 0.015MF     | 50V   | MYLAR    |
|   | C503 | QFN81HK-823  | 0.082MF     | 50V   | MYLAR    |
|   | C504 | QFN81HK-823  | 0.082MF     | 50V   | MYLAR    |
|   | C505 | QEN51HM-475  | 4.7MF       | 50V   | NON POLE |
|   | C506 | QEN51HM-475  | 4.7MF       | 50V   | NON POLE |
|   | C511 | QFN81HK-332  | 3300PF      | 50V   | MYLAR    |
|   | C512 | QFN81HK-332  | 3300PF      | 50V   | MYLAR    |
|   | C513 | QFN81HK-183  | 0.018MF     | 50V   | MYLAR    |
|   | C514 | QFN81HK-183  | 0.018MF     | 50V   | MYLAR    |
|   | C515 | QCS21HJ-221  | 220PF       | 50V   | CERAMIC  |
|   | C516 | QCS21HJ-221  | 220PF       | 50V   | CERAMIC  |
|   | C517 | QFN81HK-122  | 1200PF      | 50V   | MYLAR    |
|   | C518 | QFN81HK-122  | 1200PF      | 50V   | MYLAR    |
|   | C701 | EETB2AM-106E | 10MF        | 100V  | ELECTRO  |
|   | C702 | EETB2AM-106E | 10MF        | 100V  | ELECTRO  |
|   | C703 | QCS21HJ-470  | 47PF        | 50V   | CERAMIC  |
|   | C704 | QCS21HJ-470  | 47PF        | 50V   | CERAMIC  |
|   | C705 | QCS21HJ-101  | 100PF       | 50V   | CERAMIC  |
|   | C705 | QCS21HJ-101  | 100PF       | 50V   | CERAMIC  |
|   | C705 | QCS21HJ-330  | 33PF        | 50V   | CERAMIC  |
|   | C706 | QCS21HJ-101  | 100PF       | 50V   | CERAMIC  |
|   | C706 | QCS21HJ-101  | 100PF       | 50V   | CERAMIC  |
|   | C706 | QCS21HJ-330  | 33PF        | 50V   | CERAMIC  |
|   | C707 | QFN81HK-332  | 3300PF      | 50V   | MYLAR    |
|   | C708 | QFN81HK-332  | 3300PF      | 50V   | MYLAR    |
|   | C709 | QCS21HJ-100  | 10PF        | 50V   | CERAMIC  |
|   | C710 | QCS21HJ-100  | 10PF        | 50V   | CERAMIC  |
|   | C713 | QEN51HM-475  | 4.7MF       | 50V   | NON POLE |
|   | C714 | QEN51HM-475  | 4.7MF       | 50V   | NON POLE |
|   | C715 | QCS21HJ-330  | 33PF        | 50V   | CERAMIC  |
|   | C716 | QCS21HJ-330  | 33PF        | 50V   | CERAMIC  |
|   | C717 | QCS21HJ-330  | 33PF        | 50V   | CERAMIC  |
|   | C718 | QCS21HJ-330  | 33PF        | 50V   | CERAMIC  |
|   | C719 | QCS21HJ-220  | 22PF        | 50V   | CERAMIC  |
|   | C720 | QCS21HJ-220  | 22PF        | 50V   | CERAMIC  |
|   | C723 | QETB1CM-476  | 47MF        | 16V   | ELECTRO  |
|   | C724 | QETB1CM-476  | 47MF        | 16V   | ELECTRO  |
|   | C731 | QCS21HJ-101  | 100PF       | 50V   | CERAMIC  |
|   | C732 | QCS21HJ-101  | 100PF       | 50V   | CERAMIC  |
|   | C733 | QCS21HJ-101  | 100PF       | 50V   | CERAMIC  |
|   | C751 | QCF21HP-103  | 0.01MF      | 50V   | CERAMIC  |
|   | C752 | QCF21HP-103  | 0.01MF      | 50V   | CERAMIC  |
|   | C753 | QCF21HP-103  | 0.01MF      | 50V   | CERAMIC  |
|   | C754 | QCF22HP-103  | 0.01MF      | 50V   | CERAMIC  |
|   | C755 | QCS22HJ-470  | 47PF        | 500V  | CERAMIC  |
|   | C756 | QCS22HJ-470  | 47PF        | 500V  | CERAMIC  |
|   | C757 | QCS22HJ-470  | 47PF        | 500V  | CERAMIC  |
|   | C758 | QCS21HJ-470  | 47PF        | 500V  | CERAMIC  |
|   | C761 | QFN81HK-103  | 0.01MF      | 50V   | MYLAR    |
|   | C762 | QFN81HK-103  | 0.01MF      | 50V   | MYLAR    |
|   | C763 | QFN81HK-103  | 0.01MF      | 50V   | MYLAR    |
|   | C764 | QFN81HK-103  | 0.01MF      | 50V   | MYLAR    |
|   | C765 | QFN81HK-104  | 0.1MF       | 50V   | MYLAR    |
|   | C765 | QFN81HK-104  | 0.1MF       | 50V   | MYLAR    |
|   | C765 | QFN81HK-473  | 0.047MF     | 50V   | MYLAR    |
|   | C766 | QFN81HK-104  | 0.1MF       | 50V   | MYLAR    |
|   | C766 | QFN81HK-104  | 0.1MF       | 50V   | MYLAR    |
|   | C766 | QFN81HK-473  | 0.047MF     | 50V   | MYLAR    |
|   | C767 | QFN81HK-104  | 0.1MF       | 50V   | MYLAR    |
|   | C767 | QFN81HK-104  | 0.1MF       | 50V   | MYLAR    |
|   | C768 | QFN81HK-104  | 0.1MF       | 50V   | MYLAR    |
|   | C768 | QFN81HK-104  | 0.1MF       | 50V   | MYLAR    |
|   | C801 | EEW6304-109E | 10000MF     | 63V   | ELECTRO  |
|   | C802 | EEW6304-109E | 10000MF     | 63V   | ELECTRO  |
|   | C803 | QETB1HM-476  | 47MF        | 50V   | ELECTRO  |
|   | C804 | QETB1HM-476  | 47MF        | 50V   | ELECTRO  |
|   | C805 | QCS21HJ-101  | 100PF       | 50V   | CERAMIC  |
|   | C808 | QETB1HM-105  | 1MF         | 50V   | ELECTRO  |
|   | C809 | QETB1EM-476  | 47MF        | 25V   | ELECTRO  |
|   | C810 | QETB1EM-476  | 47MF        | 25V   | ELECTRO  |
|   | C811 | QETB1EM-106  | 10MF        | 25V   | ELECTRO  |
|   | C812 | QFN82AK-472  | 4700PF      | 100V  | MYLAR    |
|   | C813 | QETB1JM-107  | 100MF       | 63V   | ELECTRO  |
|   | C814 | QETB1JM-107  | 100MF       | 63V   | ELECTRO  |
|   | C815 | QFH42EK-104  | 0.1MF       | 250V  | M.MYLAR  |
|   | C816 | QCE22HP-103A | 0.01MF      | 500V  | CERAMIC  |
|   | C817 | QFM32AK-104  | 0.1MF       | 100V  | MYLAR    |
|   | C901 | QETB1HM-226  | 22MF        | 50V   | ELECTRO  |
|   | C902 | QETB1AM-107  | 100MF       | 10V   | ELECTRO  |
|   | C903 | QFN81HK-102  | 1000PF      | 50V   | MYLAR    |
|   | C904 | QETB1HM-475  | 4.7MF       | 50V   | ELECTRO  |
|   | C905 | QFN81HK-153  | 0.015MF     | 50V   | MYLAR    |
|   | C906 | QETB1HM-226  | 22MF        | 50V   | ELECTRO  |
|   | C907 | QCF21HP-223  | 0.022MF     | 50V   | CERAMIC  |
|   | C908 | QETB1HM-105  | 1MF         | 50V   | ELECTRO  |

△ : SAFETY PARTS

## RESISTORS

| ITEM | PART NUMBER   | DESCRIPTION |      |             | AREA |
|------|---------------|-------------|------|-------------|------|
| R501 | QVDB98C-E15B  | 100K (C)    | 50mW | VARIABLE    |      |
| R503 | QRD148J-203S  | 20K         | 1/4W | CARBON      |      |
| R504 | QRD148J-203S  | 20K         | 1/4W | CARBON      |      |
| R505 | QRD148J-362S  | 3.6K        | 1/4W | CARBON      |      |
| R506 | QRD148J-362S  | 3.6K        | 1/4W | CARBON      |      |
| R511 | QVDB98C-E15B  | 100K (C)    | 50mW | VARIABLE    |      |
| R513 | QRD148J-472S  | 4.7K        | 1/4W | CARBON      |      |
| R514 | QRD148J-472S  | 4.7K        | 1/4W | CARBON      |      |
| R515 | QRD148J-821S  | 820         | 1/4W | CARBON      |      |
| R516 | QRD148J-821S  | 820         | 1/4W | CARBON      |      |
| R701 | QRD148J-222S  | 2.2K        | 1/4W | CARBON      |      |
| R702 | QRD148J-222S  | 2.2K        | 1/4W | CARBON      |      |
| R703 | QRD148J-104S  | 100K        | 1/4W | CARBON      |      |
| R704 | QRD148J-104S  | 100K        | 1/4W | CARBON      |      |
| R705 | QRD148J-202S  | 2K          | 1/4W | CARBON      |      |
| R706 | QRD148J-202S  | 2K          | 1/4W | CARBON      |      |
| R707 | QRD148J-202S  | 2K          | 1/4W | CARBON      |      |
| R708 | QRD148J-202S  | 2K          | 1/4W | CARBON      |      |
| R709 | QRD148J-103S  | 10K         | 1/4W | CARBON      |      |
| R710 | QRD148J-103S  | 10K         | 1/4W | CARBON      |      |
| R711 | QRD148J-101S  | 100         | 1/4W | CARBON      |      |
| R712 | QRD148J-101S  | 100         | 1/4W | CARBON      |      |
| R713 | QRD14CJ-751S  | 750         | 1/4W | UNF. CARBON |      |
| R714 | QRD14CJ-751S  | 750         | 1/4W | UNF. CARBON |      |
| R715 | QRD148J-163S  | 16K         | 1/4W | CARBON      |      |
| R716 | QRD148J-163S  | 16K         | 1/4W | CARBON      |      |
| R717 | QRD148J-823S  | 82K         | 1/4W | CARBON      |      |
| R718 | QRD148J-823S  | 82K         | 1/4W | CARBON      |      |
| R719 | QRD14CJ-121S  | 120         | 1/4W | UNF. CARBON |      |
| R720 | QRD14CJ-121S  | 120         | 1/4W | UNF. CARBON |      |
| R721 | QRD125J-103   | 10K         | 1/2W | UNF. CARBON |      |
| R722 | QRD125J-103   | 10K         | 1/2W | UNF. CARBON |      |
| R725 | QRD148J-391S  | 390         | 1/4W | CARBON      |      |
| R726 | QRD148J-391S  | 390         | 1/4W | CARBON      |      |
| R727 | QRD148J-152S  | 1.5K        | 1/4W | CARBON      |      |
| R728 | QRD148J-152S  | 1.5K        | 1/4W | CARBON      |      |
| R729 | QRD148J-333S  | 33K         | 1/4W | CARBON      |      |
| R730 | QRD148J-333S  | 33K         | 1/4W | CARBON      |      |
| R731 | QRD148J-391S  | 390         | 1/4W | CARBON      |      |
| R732 | QRD148J-391S  | 390         | 1/4W | CARBON      |      |
| R733 | QRD148J-152S  | 1.5K        | 1/4W | CARBON      |      |
| R734 | QRD148J-152S  | 1.5K        | 1/4W | CARBON      |      |
| R735 | QRG012J-562AF | 5.6K        | 1W   | O.M.FILM    |      |
| R741 | QRG012J-331A  | 330         | 1W   | O.M.FILM    |      |
| R742 | QRG012J-331A  | 330         | 1W   | O.M.FILM    |      |
| R743 | QRD148J-104S  | 100K        | 1/4W | CARBON      |      |
| R744 | QRD148J-104S  | 100K        | 1/4W | CARBON      |      |
| R745 | QRD14CJ-100S  | 10          | 1/4W | UNF. CARBON | F    |
| R746 | QRD14CJ-100S  | 10          | 1/4W | UNF. CARBON | F    |
| R747 | QRD14CJ-100S  | 10          | 1/4W | UNF. CARBON | F    |
| R748 | QRD14CJ-100S  | 10          | 1/4W | UNF. CARBON | F    |
| R751 | QVZ3518-471   | 470(B)      | 0.1W | VARIABLE    |      |
| R752 | QVZ3518-471   | 470(B)      | 0.1W | VARIABLE    |      |
| R753 | QRD148J-101S  | 100         | 1/4W | CARBON      |      |
| R754 | QRD148J-101S  | 100         | 1/4W | CARBON      |      |
| R755 | ERT-D2WFL351S | 350         | 1/4W | THERMISTOR  |      |
| R756 | ERT-D2WFL351S | 350         | 1/4W | THERMISTOR  |      |
| R757 | QRD148J-471S  | 470         | 1/4W | CARBON      |      |
| R758 | QRD148J-471S  | 470         | 1/4W | CARBON      |      |
| R759 | QRD148J-391S  | 390         | 1/4W | CARBON      |      |
| R760 | QRD148J-391S  | 390         | 1/4W | CARBON      |      |
| R761 | ERT-D2WHL202S | 2K          | 1/4W | THRMISTOR   |      |
| R762 | ERT-D2WHL202S | 2K          | 1/4W | THRMISTOR   |      |
| R765 | QRZ0077-272   | 2.7K        | 1/4W | FUSIBLE     |      |
| R766 | QRZ0077-272   | 2.7K        | 1/4W | FUSIBLE     |      |
| R767 | QRZ0077-471   | 470         | 1/4W | FUSIBLE     |      |
| R768 | QRZ0077-471   | 470         | 1/4W | FUSIBLE     |      |
| R769 | QRZ0077-100   | 10          | 1/4W | FUSIBLE     |      |
| R770 | QRZ0077-100   | 10          | 1/4W | FUSIBLE     |      |
| R771 | QRZ0077-100   | 10          | 1/4W | FUSIBLE     |      |
| R772 | QRZ0077-100   | 10          | 1/4W | FUSIBLE     |      |
| R773 | ERF032K-R22   | 0.22        | 3W   | CEMENT      |      |
| R774 | ERF032K-R22   | 0.22        | 3W   | CEMENT      |      |
| R775 | QRG012J-100A  | 10          | 1W   | O.M.FILM    |      |
| R776 | QRG012J-100A  | 10          | 1W   | O.M.FILM    |      |
| R777 | QRD125J-330   | 33          | 1/2W | UNF. CARBON |      |
| R778 | QRD125J-330   | 33          | 1/2W | UNF. CARBON |      |
| R791 | QRD148J-331S  | 330         | 1/4W | CARBON      |      |
| R792 | QRD148J-331S  | 330         | 1/4W | CARBON      |      |
| R793 | QRD148J-331S  | 330         | 1/4W | CARBON      |      |
| R794 | QRD148J-331S  | 330         | 1/4W | CARBON      |      |
| R795 | QRD148J-221S  | 220         | 1/4W | CARBON      |      |
| R796 | QRD148J-221S  | 220         | 1/4W | CARBON      |      |
| R797 | QRD148J-221S  | 220         | 1/4W | CARBON      |      |
| R798 | QRD148J-221S  | 220         | 1/4W | CARBON      |      |
| R801 | QRZ0077-330   | 33          | 1/4W | FUSIBLE     |      |
| R802 | QRZ0077-330   | 33          | 1/4W | FUSIBLE     |      |

## RESISTORS

| ITEM | PART NUMBER  | DESCRIPTION |      |             | AREA |
|------|--------------|-------------|------|-------------|------|
| R803 | QRD148J-123S | 12K         | 1/4W | CARBON      |      |
| R804 | QRD148J-682S | 6.8K        | 1/4W | CARBON      |      |
| R805 | QRD148J-823S | 82K         | 1/4W | CARBON      |      |
| R806 | QRD148J-221S | 220         | 1/4W | CARBON      |      |
| R807 | QRD148J-223S | 22K         | 1/4W | CARBON      |      |
| R808 | QRD148J-203S | 20K         | 1/4W | CARBON      |      |
| R809 | QRD148J-563S | 56K         | 1/4W | CARBON      |      |
| R810 | QRD148J-123S | 12K         | 1/4W | CARBON      |      |
| R811 | QRZ0077-330  | 33          | 1/4W | FUSIBLE     |      |
| R812 | QRZ0077-330  | 33          | 1/4W | FUSIBLE     |      |
| R813 | QRD148J-123S | 12K         | 1/4W | CARBON      |      |
| R817 | QRD148J-124S | 120K        | 1/4W | CARBON      |      |
| R818 | QRD148J-124S | 120K        | 1/4W | CARBON      |      |
| R901 | QRD148J-272S | 2.7K        | 1/4W | CARBON      |      |
| R902 | QRD148J-272S | 2.7K        | 1/4W | CARBON      |      |
| R903 | QRD148J-183S | 18K         | 1/4W | CARBON      |      |
| R904 | QRD148J-183S | 18K         | 1/4W | CARBON      |      |
| R905 | QRD148J-123S | 12K         | 1/4W | CARBON      |      |
| R906 | QRD148J-123S | 12K         | 1/4W | CARBON      |      |
| R907 | QRD148J-223S | 22K         | 1/4W | CARBON      |      |
| R908 | QRD148J-223S | 22K         | 1/4W | CARBON      |      |
| R909 | QRD148J-332S | 3.3K        | 1/4W | CARBON      |      |
| R910 | QRD148J-103S | 10K         | 1/4W | CARBON      |      |
| R911 | QRD148J-104S | 100K        | 1/4W | CARBON      |      |
| R912 | QRD148J-823S | 82K         | 1/4W | CARBON      |      |
| R913 | QRD148J-473S | 47K         | 1/4W | CARBON      |      |
| R914 | QRD148J-104S | 100K        | 1/4W | CARBON      |      |
| R915 | QRD148J-683S | 68K         | 1/4W | CARBON      |      |
| R916 | QRD148J-683S | 68K         | 1/4W | CARBON      |      |
| R917 | QRD148J-203S | 20K         | 1/4W | CARBON      |      |
| R918 | QRD148J-392S | 3.9K        | 1/4W | CARBON      |      |
| R919 | QRD148J-333S | 33K         | 1/4W | CARBON      |      |
| R921 | QRD148J-224S | 220K        | 1/4W | CARBON      |      |
| R923 | QRD148J-181S | 180         | 1/4W | CARBON      |      |
| R924 | QRG022J-152A | 1.5K        | 2W   | O.M.FILM    |      |
| R925 | QRD14CJ-470S | 47          | 1/4W | UNF. CARBON |      |
| R926 | QRD148J-822S | 8.2K        | 1/4W | CARBON      |      |
| R927 | QRD148J-123S | 12K         | 1/4W | CARBON      |      |
| R928 | QRD148J-123S | 12K         | 1/4W | CARBON      |      |
| R929 | QRD148J-682S | 6.8K        | 1/4W | CARBON      |      |
| R930 | QRD148J-682S | 6.8K        | 1/4W | CARBON      |      |
| R931 | QRD148J-303S | 30K         | 1/4W | CARBON      |      |

## OTHERS


| ITEM  | PART NUMBER  | DESCRIPTION      |  |  | AREA |
|-------|--------------|------------------|--|--|------|
|       | E11417-002   | CIRCUIT BOARD    |  |  |      |
|       | E300209-019  | HEAT SINK        |  |  |      |
|       | E67292-002   | HEATSINK BRACKET |  |  |      |
|       | E67293-002   | BRACKET (R)      |  |  |      |
|       | E70945-H25   | HEAT SINK        |  |  |      |
|       | E73265-002   | SPCL SCREW       |  |  |      |
|       | SBSB3008CC   | T. SCREW         |  |  |      |
|       | SBSB3008Z    | T. SCREW         |  |  |      |
|       | SBSE3012CC   | SCREW            |  |  |      |
| J701  | EMV7112-003  | SOCKET           |  |  |      |
| J702  | QMS6A40-021  | JACK ASSY        |  |  |      |
| J703  | EMB00TP-801C | SPEAKER TERMINAL |  |  |      |
| J704  | EMB00TP-801C | SPEAKER TERMINAL |  |  |      |
| J801  | EMV7112-003  | SOCKET           |  |  |      |
| L701  | EQL0001-1R0  | INDUCTOR         |  |  |      |
| L702  | EQL0001-1R0  | INDUCTOR         |  |  |      |
| S501  | QST4102-E08  | PUSH SWITCH      |  |  |      |
| S701  | QST4241-E10  | PUSH SWITCH      |  |  |      |
| S702  | QST4241-E10  | PUSH SWITCH      |  |  |      |
| EP001 | E70859-001   | EARTH PLATE      |  |  | F    |
| EP003 | E70859-001   | EARTH PLATE      |  |  | D    |
| EP003 | E70859-001   | EARTH PLATE      |  |  | E    |
| EP003 | E70859-001   | EARTH PLATE      |  |  | F    |
| RT801 | E67764-103   | R. TERMINAL      |  |  |      |
| RY901 | ESK5D24-218  | RELAY            |  |  |      |

△ : SAFETY PARTS

■ ENE-034 □ Source Select PC Board Ass'y

Note: ENE-034 □ Varies according to the areas employed. See note (1) when placing an order.  
Note (1)

| PC Board Ass'y                        | Designated Areas                          |
|---------------------------------------|---|
| ENE-034 <input type="checkbox"/> A    | U.S. Military Market<br>& Other Countries |
| ENE-034 <input type="checkbox"/> B    | Europe, Australia                         |
| ENE-034 <input type="checkbox"/> C    | West Germany                              |
| ENE-034 <input type="checkbox"/> D BS | U.K.                                      |



| TRANSISTORS |              |             |         |
|-------------|--------------|-------------|---------|
| ITEM        | PART NUMBER  | DESCRIPTION | AREA    |
|             |              | MAKER       |         |
| Q101        | DTA144EN     | SILICON     | ROHM    |
| Q103        | 2SC2389(S,E) | SILICON     | ROHM    |
| Q104        | DTA144EN     | SILICON     | ROHM    |
| Q105        | DTA144EN     | SILICON     | ROHM    |
| Q107        | 2SK163(L1)   | F.E.T       | NEC     |
| Q108        | 2SK163(L1)   | F.E.T       | NEC     |
| Q301        | 2SK170(BL)   | F.E.T       | TOSHIBA |
| Q302        | 2SK170(BL)   | F.E.T       | TOSHIBA |
| Q303        | 2SK170(BL)   | F.E.T       | TOSHIBA |
| Q304        | 2SK170(BL)   | F.E.T       | TOSHIBA |
| Q305        | 2SD655(E,F)  | SILICON     | HITACHI |
| Q306        | 2SD655(E,F)  | SILICON     | HITACHI |
| Q307        | 2SD655(E,F)  | SILICON     | HITACHI |
| Q308        | 2SD655(E,F)  | SILICON     | HITACHI |

| I.C. S |             |             |            |
|--------|-------------|-------------|------------|
| ITEM   | PART NUMBER | DESCRIPTION | AREA       |
|        |             | MAKER       |            |
| IC101  | LC7818      | I.C.        | SANYO      |
| IC102  | TA7317P     | I.C.        | TOSHIBA    |
| IC301  | M5219P      | I.C.        | MITSUBISHI |

△ : SAFETY PARTS

## DIODES

| ITEM | PART NUMBER | DESCRIPTION | AREA  |
|------|-------------|-------------|-------|
|      |             |             | MAKER |
| D101 | 1SS133      | SILICON     | ROHM  |
| D102 | 1SS133      | SILICON     | ROHM  |
| D103 | 1SS133      | SILICON     | ROHM  |
| D104 | 1SS133      | SILICON     | ROHM  |
| D105 | 1SS133      | SILICON     | ROHM  |
| D106 | 1SS133      | SILICON     | ROHM  |
| D107 | MTZ15JC     | ZENER       | ROHM  |
| D108 | MTZ15JC     | ZENER       | ROHM  |
| D109 | MTZ15JC     | ZENER       | ROHM  |
| D110 | MTZ15JC     | ZENER       | ROHM  |
| D111 | 1SS133      | SILICON     | ROHM  |
| D112 | 1SS133      | SILICON     | ROHM  |
| D113 | MTZ5.6JC    | ZENER       | ROHM  |
| D115 | MTZ13JC     | ZENER       | ROHM  |
| D116 | MTZ13JC     | ZENER       | ROHM  |
| D117 | MTZ6.8JC    | ZENER       | ROHM  |
| D211 | SLR-34VR3F  | L.E.D.      | ROHM  |
| D212 | SLR-34DU3F  | L.E.D.      | ROHM  |
| D213 | SLR-34DU3F  | L.E.D.      | ROHM  |
| D214 | SLR-34DU3F  | L.E.D.      | ROHM  |
| D215 | SLR-34DU3F  | L.E.D.      | ROHM  |

## CAPACITORS

| ITEM | PART NUMBER  | DESCRIPTION |      |         |  | AREA |
|------|--------------|-------------|------|---------|--|------|
| C307 | QCS21HJ-470  | 47PF        | 50V  | CERAMIC |  | B    |
| C307 | QCS21HJ-470  | 47PF        | 50V  | CERAMIC |  | DBS  |
| C308 | QCS21HJ-331  | 330PF       | 50V  | CERAMIC |  | C    |
| C308 | QCS21HJ-470  | 47PF        | 50V  | CERAMIC |  | A    |
| C308 | QCS21HJ-470  | 47PF        | 50V  | CERAMIC |  | B    |
| C308 | QCS21HJ-470  | 47PF        | 50V  | CERAMIC |  | DBS  |
| C309 | QFN81HK-392  | 3900PF      | 50V  | MYLAR   |  |      |
| C310 | QFN81HK-392  | 3900PF      | 50V  | MYLAR   |  |      |
| C311 | QFN81HK-822  | 8200PF      | 50V  | MYLAR   |  |      |
| C312 | QFN81HK-822  | 8200PF      | 50V  | MYLAR   |  |      |
| C313 | QCS21HJ-101  | 100PF       | 50V  | CERAMIC |  | A    |
| C313 | QCS21HJ-101  | 100PF       | 50V  | CERAMIC |  | B    |
| C313 | QCS21HJ-101  | 100PF       | 50V  | CERAMIC |  | DBS  |
| C313 | QCS21HJ-330  | 33PF        | 50V  | CERAMIC |  | C    |
| C314 | QCS21HJ-101  | 100PF       | 50V  | CERAMIC |  | A    |
| C314 | QCS21HJ-101  | 100PF       | 50V  | CERAMIC |  | B    |
| C314 | QCS21HJ-101  | 100PF       | 50V  | CERAMIC |  | DBS  |
| C314 | QCS21HJ-330  | 33PF        | 50V  | CERAMIC |  | C    |
| C315 | QFN81HK-473  | 0.047MF     | 50V  | MYLAR   |  |      |
| C316 | QFN81HK-473  | 0.047MF     | 50V  | MYLAR   |  |      |
| C317 | QETB0JM-228  | 2200MF      | 6.3V | ELECTRO |  |      |
| C318 | QETB0JM-228  | 2200MF      | 6.3V | ELECTRO |  |      |
| C319 | QFN81HJ-472  | 4700PF      | 50V  | MYLAR   |  |      |
| C320 | QFN81HJ-472  | 4700PF      | 50V  | MYLAR   |  |      |
| C321 | QCS21HJ-331  | 330PF       | 50V  | CERAMIC |  |      |
| C322 | QCS21HJ-331  | 330PF       | 50V  | CERAMIC |  |      |
| C323 | QFN81HJ-153  | 0.015MF     | 50V  | MYLAR   |  |      |
| C324 | QFN81HJ-153  | 0.015MF     | 50V  | MYLAR   |  |      |
| C325 | QFN81HJ-272  | 2700PF      | 50V  | MYLAR   |  |      |
| C326 | QFN81HJ-272  | 2700PF      | 50V  | MYLAR   |  |      |
| C327 | EETB2AM-106E | 10M         | 100V | ELECTRO |  |      |
| C328 | EETB2AM-106E | 10M         | 100V | ELECTRO |  |      |
| C331 | QCS21HK-222  | 2200PF      | 50V  | CERAMIC |  | C    |
| C332 | QCS21HK-222  | 2200PF      | 50V  | CERAMIC |  | C    |

## CAPACITORS

| ITEM | PART NUMBER   | DESCRIPTION |      |         |  | AREA |
|------|---------------|-------------|------|---------|--|------|
| C001 | QCZ9019-472   | 4700PF      | 400V | CERAMIC |  | B    |
| C001 | QCZ9019-472   | 4700PF      | 400V | CERAMIC |  | C    |
| C001 | QCZ9019-472BS | 4700PF      | 400V | CERAMIC |  | DBS  |
| C101 | QFS81HJ-221   | 220PF       | 50V  | POLY    |  | C    |
| C102 | QFS81HJ-221   | 220PF       | 50V  | POLY    |  | C    |
| C103 | QCS21HJ-221   | 220PF       | 50V  | CERAMIC |  | C    |
| C104 | QCS21HJ-221   | 220PF       | 50V  | CERAMIC |  | C    |
| C105 | QCS21HJ-221   | 220PF       | 50V  | CERAMIC |  | C    |
| C106 | QCS21HJ-221   | 220PF       | 50V  | CERAMIC |  | C    |
| C107 | QCS21HJ-221   | 220PF       | 50V  | CERAMIC |  | C    |
| C108 | QCS21HJ-221   | 220PF       | 50V  | CERAMIC |  | C    |
| C109 | QCS21HJ-221   | 220PF       | 50V  | CERAMIC |  | C    |
| C110 | QCS21HJ-221   | 220PF       | 50V  | CERAMIC |  | C    |
| C111 | QCS21HJ-221   | 220PF       | 50V  | CERAMIC |  | C    |
| C112 | QCS21HJ-221   | 220PF       | 50V  | CERAMIC |  | C    |
| C113 | QCF21HP-473   | 0.047MF     | 50V  | CERAMIC |  |      |
| C114 | QCF21HP-223   | 0.022MF     | 50V  | CERAMIC |  |      |
| C115 | QCF21HP-223   | 0.022MF     | 50V  | CERAMIC |  |      |
| C116 | QCF21HP-223   | 0.022MF     | 50V  | CERAMIC |  |      |
| C117 | QCF21HP-223   | 0.022MF     | 50V  | CERAMIC |  |      |
| C118 | QCF21HP-473   | 0.047MF     | 50V  | CERAMIC |  |      |
| C119 | QCF21HP-223   | 0.022MF     | 50V  | CERAMIC |  |      |
| C121 | QCS21HJ-221   | 220PF       | 50V  | CERAMIC |  | C    |
| C122 | QCS21HJ-221   | 220PF       | 50V  | CERAMIC |  | C    |
| C125 | QCS21HJ-221   | 220PF       | 50V  | CERAMIC |  | C    |
| C126 | QCS21HJ-221   | 220PF       | 50V  | CERAMIC |  | C    |
| C127 | QCF21HP-223   | 0.022MF     | 50V  | CERAMIC |  |      |
| C131 | QETB1EM-107   | 100MF       | 25V  | ELECTRO |  |      |
| C132 | QETB1EM-107   | 100MF       | 25V  | ELECTRO |  |      |
| C133 | QETB1HM-475   | 4.7MF       | 50V  | ELECTRO |  |      |
| C146 | QFN81HJ-562   | 5600PF      | 50V  | MYLAR   |  |      |
| C147 | EEZ0502-479   | 47000MF     | 6.5V | ELECTRO |  |      |
| C148 | QFN81HJ-562   | 5600PF      | 50V  | MYLAR   |  |      |
| C149 | QFN81HK-473   | 0.047MF     | 50V  | MYLAR   |  |      |
| C150 | QETB1HM-225   | 2.2MF       | 50V  | ELECTRO |  |      |
| C151 | QCS21HJ-331   | 330PF       | 50V  | CERAMIC |  |      |
| C152 | QETB1CM-226   | 22MF        | 16V  | ELECTRO |  |      |
| C153 | QETB1HM-475   | 4.7MF       | 50V  | ELECTRO |  |      |
| C154 | QETB1CM-107   | 100MF       | 16V  | ELECTRO |  |      |
| C155 | QETB1HM-474   | 0.47MF      | 50V  | ELECTRO |  |      |
| C159 | QCS21HJ-101   | 100PF       | 50V  | CERAMIC |  | C    |
| C160 | QCS21HJ-101   | 100PF       | 50V  | CERAMIC |  | C    |
| C161 | QCS21HJ-221   | 220PF       | 50V  | CERAMIC |  | C    |
| C162 | QCS21HJ-221   | 220PF       | 50V  | CERAMIC |  | C    |
| C201 | QFN81HK-333   | 0.033MF     | 50V  | MYLAR   |  |      |
| C202 | QFN81HK-333   | 0.033MF     | 50V  | MYLAR   |  |      |
| C203 | QCS21HJ-181   | 180PF       | 50V  | CERAMIC |  |      |
| C204 | QCS21HJ-181   | 180PF       | 50V  | CERAMIC |  |      |
| C205 | QCS21HJ-470   | 47PF        | 50V  | CERAMIC |  | C    |
| C206 | QCS21HJ-470   | 47PF        | 50V  | CERAMIC |  | C    |
| C303 | QCS21HJ-151   | 150PF       | 50V  | CERAMIC |  |      |
| C304 | QCS21HJ-151   | 150PF       | 50V  | CERAMIC |  |      |
| C305 | QFN81HK-103   | 0.01MF      | 50V  | MYLAR   |  |      |
| C306 | QFN81HK-103   | 0.01MF      | 50V  | MYLAR   |  |      |
| C307 | QCS21HJ-331   | 330PF       | 50V  | CERAMIC |  | C    |
| C307 | QCS21HJ-470   | 47PF        | 50V  | CERAMIC |  | A    |

## RESISTORS

| ITEM | PART NUMBER  | DESCRIPTION |      |          |  | AREA |
|------|--------------|-------------|------|----------|--|------|
| R101 | QRD161J-4R7  | 4.7         | 1/6W | CARBON   |  |      |
| R103 | QRD161J-104  | 100K        | 1/6W | CARBON   |  |      |
| R104 | QRD161J-104  | 100K        | 1/6W | CARBON   |  |      |
| R105 | QRD161J-471  | 470         | 1/6W | CARBON   |  |      |
| R106 | QRD161J-471  | 470         | 1/6W | CARBON   |  |      |
| R111 | QRD161J-471  | 470         | 1/6W | CARBON   |  |      |
| R112 | QRD161J-471  | 470         | 1/6W | CARBON   |  |      |
| R113 | QRD161J-471  | 470         | 1/6W | CARBON   |  |      |
| R114 | QRD161J-471  | 470         | 1/6W | CARBON   |  |      |
| R115 | QRD161J-471  | 470         | 1/6W | CARBON   |  |      |
| R116 | QRD161J-471  | 470         | 1/6W | CARBON   |  |      |
| R117 | QRD161J-471  | 470         | 1/6W | CARBON   |  |      |
| R117 | QRD161J-471  | 470         | 1/6W | CARBON   |  | B    |
| R117 | QRD161J-182  | 1.8K        | 1/6W | CARBON   |  | DBS  |
| R118 | QRD161J-471  | 470         | 1/6W | CARBON   |  | C    |
| R118 | QRD161J-471  | 470         | 1/6W | CARBON   |  | A    |
| R118 | QRD161J-182  | 1.8K        | 1/6W | CARBON   |  | B    |
| R119 | QRD161J-471  | 470         | 1/6W | CARBON   |  | DBS  |
| R120 | QRD161J-471  | 470         | 1/6W | CARBON   |  | C    |
| R120 | QRD161J-471  | 470         | 1/6W | CARBON   |  | A    |
| R123 | QRZ0077-101  | 100         | 1/4W | FUSIBLE  |  |      |
| R124 | QRZ0077-101  | 100         | 1/4W | FUSIBLE  |  |      |
| R126 | QRD161J-104  | 100K        | 1/6W | CARBON   |  |      |
| R127 | QRD161J-104  | 100K        | 1/6W | CARBON   |  |      |
| R131 | QRD161J-103  | 10K         | 1/6W | CARBON   |  |      |
| R132 | QRD161J-103  | 10K         | 1/6W | CARBON   |  |      |
| R133 | QRD161J-105  | 1M          | 1/6W | CARBON   |  |      |
| R134 | QRD161J-103  | 10K         | 1/6W | CARBON   |  |      |
| R135 | QRD161J-474  | 470K        | 1/6W | CARBON   |  |      |
| R136 | QRD161J-562  | 5.6K        | 1/6W | CARBON   |  |      |
| R137 | QRD161J-473  | 47K         | 1/6W | CARBON   |  |      |
| R138 | QRD161J-392  | 3.9K        | 1/6W | CARBON   |  |      |
| R139 | QRD161J-104  | 100K        | 1/6W | CARBON   |  |      |
| R140 | QRD161J-104  | 100K        | 1/6W | CARBON   |  |      |
| R141 | QRD161J-223  | 22K         | 1/6W | CARBON   |  |      |
| R143 | QRD161J-102  | 1K          | 1/6W | CARBON   |  |      |
| R144 | QRD161J-102  | 1K          | 1/6W | CARBON   |  |      |
| R146 | QRD161J-122  | 1.2K        | 1/6W | CARBON   |  |      |
| R147 | QRD161J-473  | 47K         | 1/6W | CARBON   |  |      |
| R148 | QRD161J-273  | 27K         | 1/6W | CARBON   |  |      |
| R201 | QRD161J-562  | 5.6K        | 1/6W | CARBON   |  |      |
| R202 | QRD161J-562  | 5.6K        | 1/6W | CARBON   |  |      |
| R203 | QRD161J-472  | 4.7K        | 1/6W | CARBON   |  |      |
| R204 | QRD161J-472  | 4.7K        | 1/6W | CARBON   |  |      |
| R205 | QVDA98W-EF5B | 250K(W)     | 0.3W | VARIABLE |  |      |

△ : SAFETY PARTS

### RESISTORS

| ITEM | PART NUMBER   | DESCRIPTION           | AREA |
|------|---------------|-----------------------|------|
| R207 | QRD161J-223   | 22K 1/6W CARBON       |      |
| R208 | QRD161J-223   | 22K 1/6W CARBON       |      |
| R209 | QRD161J-105   | 1M 1/6W CARBON        |      |
| R210 | QRD161J-105   | 1M 1/6W CARBON        |      |
| R211 | QVD8A7B-AF5VA | 250K(W) 50mW VARIABLE |      |
| R251 | QRD161J-122   | 1.2K 1/6W CARBON      |      |
| R252 | QRD161J-122   | 1.2K 1/6W CARBON      |      |
| R253 | QRD161J-122   | 1.2K 1/6W CARBON      |      |
| R254 | QRD161J-122   | 1.2K 1/6W CARBON      |      |
| R255 | QRD161J-122   | 1.2K 1/6W CARBON      |      |
| R256 | QRD161J-122   | 1.2K 1/6W CARBON      |      |
| R257 | QRD161J-122   | 1.2K 1/6W CARBON      |      |
| R258 | QRD161J-122   | 1.2K 1/6W CARBON      |      |
| R259 | QRD161J-122   | 1.2K 1/6W CARBON      |      |
| R260 | QRD161J-122   | 1.2K 1/6W CARBON      |      |
| R265 | QRD161J-104   | 100K 1/6W CARBON      |      |
| R301 | QRD161J-102   | 1K 1/6W CARBON        | C    |
| R302 | QRD161J-102   | 1K 1/6W CARBON        | C    |
| R303 | QRD161J-473   | 47K 1/6W CARBON       |      |
| R304 | QRD161J-473   | 47K 1/6W CARBON       |      |
| R305 | QRD161J-471   | 470 1/6W CARBON       |      |
| R306 | QRD161J-471   | 470 1/6W CARBON       |      |
| R307 | QRD161J-5R6   | 5.6 1/6W CARBON       |      |
| R308 | QRD161J-5R6   | 5.6 1/6W CARBON       |      |
| R309 | QRD161J-101   | 100 1/6W CARBON       |      |
| R310 | QRD161J-101   | 100 1/6W CARBON       |      |
| R311 | QRD161J-562   | 5.6K 1/6W CARBON      |      |
| R312 | QRD161J-562   | 5.6K 1/6W CARBON      |      |
| R313 | QRD161J-270   | 27 1/6W CARBON        |      |
| R314 | QRD161J-270   | 27 1/6W CARBON        |      |
| R315 | QRD161J-561   | 560 1/6W CARBON       |      |
| R316 | QRD161J-561   | 560 1/6W CARBON       |      |
| R317 | QRD161J-562   | 5.6K 1/6W CARBON      |      |
| R318 | QRD161J-562   | 5.6K 1/6W CARBON      |      |
| R319 | QRD161J-222   | 2.2K 1/6W CARBON      |      |
| R320 | QRD161J-222   | 2.2K 1/6W CARBON      |      |
| R321 | QRD161J-272   | 2.7K 1/6W CARBON      |      |
| R322 | QRD161J-272   | 2.7K 1/6W CARBON      |      |
| R323 | QRD161J-273   | 27K 1/6W CARBON       |      |
| R324 | QRD161J-273   | 27K 1/6W CARBON       |      |
| R325 | QRD161J-273   | 27K 1/6W CARBON       |      |
| R326 | QRD161J-273   | 27K 1/6W CARBON       |      |
| R327 | QRD161J-150   | 15 1/6W CARBON        | C    |
| R327 | QRD161J-180   | 18 1/6W CARBON        | A    |
| R327 | QRD161J-180   | 18 1/6W CARBON        | B    |
| R327 | QRD161J-180   | 18 1/6W CARBON        | DBS  |
| R328 | QRD161J-150   | 15 1/6W CARBON        | C    |
| R328 | QRD161J-180   | 18 1/6W CARBON        | A    |
| R328 | QRD161J-180   | 18 1/6W CARBON        | B    |
| R328 | QRD161J-180   | 18 1/6W CARBON        | DBS  |
| R329 | QRD161J-221   | 220 1/6W CARBON       |      |
| R330 | QRD161J-221   | 220 1/6W CARBON       |      |
| R331 | QRD161J-153   | 15K 1/6W CARBON       |      |
| R332 | QRD161J-153   | 15K 1/6W CARBON       |      |
| R333 | QRD161J-184   | 180K 1/6W CARBON      |      |
| R334 | QRD161J-184   | 180K 1/6W CARBON      |      |
| R335 | QRD161J-331   | 330 1/6W CARBON       |      |
| R336 | QRD161J-331   | 330 1/6W CARBON       |      |
| R337 | QRD161J-104   | 100K 1/6W CARBON      |      |
| R338 | QRD161J-104   | 100K 1/6W CARBON      |      |


### OTHERS

| ITEM | PART NUMBER  | DESCRIPTION     | AREA |
|------|--------------|-----------------|------|
|      | EMG7331-001  | FUSE CLIP       |      |
|      | ENZ2006-001  | SHIELD CASE     | C    |
|      | EWTO11-091   | TERMINAL WIRE   |      |
|      | E03532-001   | SHIELD CASE     | C    |
|      | E11418-002   | CIRCUIT BOARD   | A    |
|      | E11418-002   | CIRCUIT BOARD   | B    |
|      | E11418-002   | CIRCUIT BOARD   | C    |
|      | E11418-002BS | CIRCUIT BOARD   | DBS  |
|      | E65508-002   | TAB             | B    |
|      | E65508-002   | TAB             | C    |
|      | E65508-002   | TAB             | DBS  |
|      | E67132-T2R5  | T2R5 FUSE LABEL |      |
|      | E67132-T4R0  | T4R0 FUSE LABEL | A    |
|      | E67764-202   | R.TERMINAL      |      |
|      | E67764-203   | TERMINAL.ASSY   | B    |
|      | E67764-203   | TERMINAL.ASSY   | C    |
|      | E67764-203   | TERMINAL.ASSY   | DBS  |
|      | E74008-001   | SHIELD BKT      |      |
| J101 | EMN00TV-405A | PIN JACK ASSY   |      |
| J102 | EMN00TV-402A | PIN JACK ASSY   |      |
| J103 | EMN00TV-402A | PIN JACK ASSY   |      |
| J104 | EMN00TP-404A | PIN JACK ASSY   |      |
| J105 | E03623-003   | DIN SOCKET      |      |
| J109 | EMV7112-009  | SOCKET          |      |
| L301 | EQL0111-391  | INDUCTOR        | C    |
| L302 | EQL0111-391  | INDUCTOR        | C    |
| S201 | ESP0001-007  | PUSH SWITCH     |      |
| S202 | ESP0001-007  | PUSH SWITCH     |      |
| S203 | ESP0001-007  | PUSH SWITCH     |      |
| S204 | ESP0001-007  | PUSH SWITCH     |      |
| S205 | ESP0001-007  | PUSH SWITCH     |      |
| S206 | QST4261-E11  | PUSH SWITCH     |      |
| S207 | QST4261-E11  | PUSH SWITCH     |      |
| S208 | QST4102-E08  | PUSH SWITCH     |      |
| S209 | QST4102-E08  | PUSH SWITCH     |      |

△ : SAFETY PARTS

### ■ TPS-318 [A] Voltage Selector PC Board Ass'y

(Except for Europe, Australia, West Germany, U.K.)




### CAPACITORS

| ITEM | PART NUMBER  | DESCRIPTION         | AREA |
|------|--------------|---------------------|------|
| C001 | QFH53BM-103M | 0.01MF 250V M.MYLAR |      |

### OTHERS

| ITEM | PART NUMBER  | DESCRIPTION   | AREA |
|------|--------------|---------------|------|
|      | E302057-001  | CIRCUIT BOARD |      |
|      | E43727-001   | TAB           |      |
|      | E65508-001   | TAB           |      |
|      | QMC0637-004  | AC SOCKET     |      |
|      | QSR0085-006U | V.SELECTOR    |      |

Packing Materials and Part Numbers



Accessories List

| ⚠ | Item No. | Part Number    | Part Name                | Q'ty | Description     | Areas             |
|---|----------|----------------|--------------------------|------|-----------------|-------------------|
|   |          | E30580-1366A   | Instruction Book         | 1    |                 | P, PG, E, A, G, U |
|   |          | E30580-1366ABS | Instruction Book         | 1    |                 | BS                |
|   |          | BT20046C       | Service Information Card | 1    |                 | P, PG             |
|   |          | BT20048C       | Warranty Card            | 1    |                 | P, PG             |
|   |          | BT20029C       | Warranty Card            | 1    | for Australia   | A                 |
|   |          | BT20098        | Warranty Card            | 1    | for New Zealand | A                 |
|   |          | BT20064        | Warranty Card            | 1    |                 | G                 |
|   |          | BT20066        | EEC AGENCY               | 1    |                 | G, BS             |
|   |          | BT20060        | Warranty Card            | 1    |                 | BS                |
|   |          | QZL1008-001    | FTZ Information Sheet    | 1    |                 | G                 |
|   |          | E04056         | Siemens Plug             | 1    |                 | PG, U             |
|   |          | E41202-2       | Envelope                 | 1    |                 | P, PG, E, A, G, U |
|   |          | E41202-2B      | Envelope                 | 1    |                 | BS                |

⚠ : Safety Parts

The Marks for Designated Areas


- P, PG..... U.S. Military Market
- E ..... Europe
- A ..... Australia
- G ..... West Germany
- BS ..... U.K.
- U ..... Other Countries

No mark indicates all areas.




# Internal Block Diagrams of ICs

## ■ LC7818 (IC101)



## ■ M5219P (IC301)



## ■ TA7317P (IC102, IC901)

## ■ VC5022 [X, Y] (IC751, IC752)

